


**SMARTCAP®**

## **INSTRUCTION GUIDE FORD RANGER EDITION 2024-CURRENT (5th Generation)**



- ▼ **PREPARE A CLEAN WORK AREA.**
- ▼ **WE RECOMMEND A MINIMUM OF 2 PEOPLE FOR ASSEMBLY AND 4 PEOPLE FOR INSTALLATION.**
- ▼ **ENSURE THE REQUIRED TOOLS ARE PRESENT AND ALL HARDWARE CONTENTS ARE ACCOUNTED FOR.**
- ▼ **NEVER USE ACETONE OR THINNERS ON PAINTED PARTS.**
- ▼ **READ THROUGH THE ENTIRE INSTRUCTION GUIDE BEFORE STARTING THIS PROCEDURE AND FOLLOW THE STEPS CAREFULLY TO AVOID ANY DAMAGE TO THE COMPONENTS OR THE VEHICLE.**

**SMARTCAP.COM**

**SUPPORT.NA@SMARTCAP.COM - NORTH AMERICA**

**SUPPORT.SA@SMARTCAP.COM - REST OF WORLD**




**I-SHEET-NA-R2**



## DISCLAIMER

IT IS A REQUIREMENT FROM FORD THAT ANY 2024 NEXT GEN RANGER PRODUCED ON OR BEFORE 09/19/24 WITH ACCESSORIES EXTENDING ABOVE THE BEDRAILS, AND WEIGHING IN EXCESS OF 88 LBS., BE FITTED WITH THE LOAD BOX REINFORCEMENT BRACKETS (AKA J-BRACES). THESE MAY BE PURCHASED THROUGH ANY AUTHORIZED FORD DEALER AND WILL NEED TO BE INSTALLED PRIOR TO INSTALLATION OF A SMARTCAP TO AVOID NEGATIVELY IMPACTING YOUR VEHICLE'S FACTORY WARRANTY. USE PT #VN1WZ2627726A FOR MOST TRIM LEVELS, OR PT #VN1WZ26277236B FOR RAPTORS. THESE ARE NOT NECESSARY FOR RANGERS PRODUCED AFTER 09/19/24. PLEASE CONSULT YOUR OWNER'S MANUAL OR SELLING DEALER FOR MORE INFORMATION. SEE YOUR OWNER'S MANUAL OR SELLING DEALER FOR MORE INFORMATION.


## TOOLS REQUIRED




## IMPORTANT

- ▼ USE ONLY THE TOOLS RECOMMENDED ABOVE.
- ▼ USE ONLY THE HARDWARE PROVIDED IN THIS KIT.
- ▼ ASSISTANCE WILL BE NEEDED FOR THIS INSTALLATION. FOUR PEOPLE ARE RECOMMENDED TO LIFT THE SMARTCAP ONTO THE VEHICLE.
- ▼ AVOID PINCHING OR CRUSHING HANDS AND FINGERS.
- ▼ INSPECT ALL KIT COMPONENTS FOR DAMAGE BEFORE ASSEMBLY.
- ▼ NEVER USE ACETONE OR THINNERS ON PAINTED PARTS.


## COMPONENTS




ROOF PANEL




REAR FLANGE



FRONT FLANGE



LEFT PANEL




RIGHT PANEL


## ASSEMBLY HARDWARE

### FITMENT KIT

**M6 x 10mm BOLT**




**FASTENER  
BLOCK CLAMP**



**M6 LOCK  
WASHER**




**FASTENER  
BLOCK**



**D - RUBBER**



**SPARE PARTS**



### PRE-FASTENED TO ROOF PANEL

**M6 FENDER  
WASHER**



**M6 LOCK  
NUT**




## STEP 1





### IMPORTANT

- ▼ BE SURE TO REMOVE ALL FIVE PANELS FROM THEIR PACKAGING AND INSPECT THE PAINTED SURFACES PRIOR TO ASSEMBLY, AS SMARTCAP WILL NOT ACCEPT WARRANTY CLAIMS AFTER ASSEMBLY IS COMPLETED. IF MANUFACTURING IMPERFECTIONS OR SHIPPING DAMAGES ARE FOUND, DO NOT CONTINUE WITH THE ASSEMBLY PROCESS AND CONTACT [SUPPORT.NA@SMARTCAP.COM](mailto:SUPPORT.NA@SMARTCAP.COM).



## STEP 2

PLACE THE ROOF PANEL WHERE YOU PLAN TO ASSEMBLE THE CAP. REMOVE THE LID FROM THE PACKAGING AND PLACE IT NEXT TO THE ROOF PANEL.




## STEP 3

USE A 10MM COMBINATION WRENCH TO REMOVE ALL HARDWARE FROM THE ROOF PANEL AND SAVE FOR REUSE.



**AIR VENT INDICATES REAR**




## STEP 4

LOCATE THE RIGHT PANEL IN THE SMARTCAP PACKAGE AND BRING IT TO YOUR WORK AREA.

**2 PERSON JOB**



**SLANTED EDGE INDICATES REAR**




## STEP 5

INSERT PANEL TABS INTO  
NARROW SLOTS JUST ABOVE  
FOAM PADDING ON ROOF PANEL.


TAP FIRMLY WITH PALM OF HAND  
UNTIL THERE IS A 2-3MM GAP.

2 PERSON JOB



## STEP 6

HAND TIGHTEN M6 LOCK NUT WITH  
M6 FENDER WASHER TO ALL BOLTS.




## STEP 7

LOCATE THE LEFT PANEL IN THE SMARTCAP PACKAGE AND BRING IT TO YOUR WORK AREA.

2 PERSON JOB



**SLANTED EDGE INDICATES REAR**




## STEP 8

INSERT PANEL TABS INTO NARROW SLOTS JUST ABOVE FOAM PADDING ON ROOF PANEL.

2 PERSON JOB




TAP FIRMLY WITH PALM OF HAND UNTIL THERE IS A 2-3MM GAP.




## STEP 9

HAND TIGHTEN M6 LOCK NUT WITH  
M6 FENDER WASHER TO ALL BOLTS.



## STEP 10

PUSH THE SMARTCAP TO EXPOSE A FEW INCHES OF  
STYRAFOAM UNDERNEATH THE ROOF PANEL TO  
PROVIDE SUPPORT FOR THE FRONT FLANGE.





## STEP 11

RETRIEVE THE NECESSARY HARDWARE FROM THE FITMENT KIT.

LOCATE THE FRONT FLANGE IN THE SMARTCAP PACKAGE AND BRING IT TO YOUR WORK AREA.

2 PERSON JOB



14X




14X



14X




14X



## STEP 12

PLACE FRONT FLANGE AS SHOWN BELOW.

2 PERSON JOB





## STEP 13

INSTALL HARDWARE ALONG FRONT FLANGE WITH M6 BOLT ON INSIDE.

START WITH ASSEMBLING FASTENER BLOCKS 1-5.


ADJUST LEFT AND RIGHT PANELS TO ALIGN FASTENER BLOCKS 6-15 FOR ASSEMBLY.

HAND TIGHTEN IN THE SEQUENCE SHOWN.



## STEP 14

PUSH THE SMARTCAP TO EXPOSE A FEW INCHES OF STYROFOAM UNDERNEATH THE ROOF PANEL TO PROVIDE SUPPORT FOR THE REAR FLANGE.




## STEP 15

RETRIEVE THE NECESSARY HARDWARE FROM THE FITMENT KIT.

LOCATE THE REAR FLANGE IN THE SMARTCAP PACKAGE AND BRING IT TO YOUR WORK AREA.


2 PERSON JOB



## STEP 16

PLACE REAR FLANGE AS SHOWN BELOW.

2 PERSON JOB





## STEP 17

INSTALL HARDWARE ALONG REAR FLANGE WITH BOLT ON INSIDE.

START WITH ASSEMBLING FASTENER BLOCKS 1-5.

ADJUST LEFT AND RIGHT PANELS TO ALIGN FASTENER BLOCKS 6-15 FOR ASSEMBLY.

HAND TIGHTEN IN THE SEQUENCE SHOWN.




## STEP 18

TIGHTEN ALL HARDWARE WITH TORQUE WRENCH AND 10MM SOCKET TO 3.7 FT. LBS. [5 NEWTON METERS]




**[3.7 ft. lbs]/[5 Nm]**




## STEP 19


- A** LOCATE THE D-RUBBER RETENTION TAB NEXT TO THE REAR DOOR GASKET. BEND THE TAB UPWARDS AT A 45 DEGREE ANGLE.




- B** PEEL AWAY A SMALL PORTION OF THE ADHESIVE BACKING FROM THE D-RUBBER.




- C** INSERT THE TAB INTO THE D-RUBBER UNTIL THE D-RUBBER LIGHTLY BUTTS UP AGAINST REAR DOOR GASKET.




- D** FIRMLY PUSH THE TAB BACK DOWN TO SECURE THE D-RUBBER IN PLACE.



**CORRECT D-RUBBER ORIENTATION**



**INCORRECT D-RUBBER ORIENTATION**




## STEP 20

PEEL AWAY ADHESIVE BACKING IN SHORT LENGTHS AS YOU WORK AROUND THE EDGES.



STAY WITHIN 1/8 INCH FROM THE SMARTCAP'S OUTER EDGES.

REMOVE EXCESS WITH A STRAIGHT CUT.




## INSTALLATION HARDWARE

### MOUNTING BRACKETS



### 25mm x 25mm FOAM SEAL TAPE




### M8 x 20mm BOLT



### M8 LOCK WASHER



### ALUMINUM SPACER BLOCK



### M8 x 20mm BUTTON BOLT



### M8 LOCK NUT



### M8 FENDER WASHER



## VEHICLE INSTALLATION



### IMPORTANT

- ▼ ASSISTANCE WILL BE NEEDED FOR THIS INSTALLATION. FOUR PEOPLE ARE RECOMMENDED TO LIFT THE SMARTCAP ONTO THE VEHICLE.
- ▼ AVOID PINCHING OR CRUSHING HANDS AND FINGERS.
- ▼ READ THROUGH THE ENTIRE PROCEDURE BEFORE STARTING.

## BED RAIL CAP WARNING




### PRIOR TO INSTALLATION

- ▼ TO INSURE YOU DO NOT DAMAGE YOUR TRUCK OR THE SMARTCAP, IT IS IMPORTANT TO EXAMINE THE BED RAILS OF YOUR VEHICLE TO ACCURATELY DETERMINE WHICH MODEL YEAR YOU HAVE.

## STEP 21-22

IF YOUR BED RAIL STAKE POCKET COVERS LOOK LIKE PICTURE A, PLEASE MOVE TO STEP 21


PICTURE A



## STEP 23

IF YOUR BED RAIL STAKE POCKET COVERS LOOK LIKE PICTURE B, PLEASE MOVE TO STEP 23


PICTURE B



## STEP 21

REMOVE THE CENTER TWO BED-RAIL  
CAP INSERTS AND PLACE THEM  
IN THE GLOVE BOX.



**REPEAT ON THE OPPOSITE  
SIDE OF THE VEHICLE.**



## STEP 22

PLACE THE ALUMINUM SPACER BLOCK  
ONTO THE METAL BED-RAIL AS SHOWN.



**REPEAT ON THE OPPOSITE  
SIDE OF THE VEHICLE.**





## STEP 23

INSPECT THE TRUCK BED. IF FRONT EDGE IS LOWER THAN THE SIDES, ADD FOAM SEAL TAPE TO THE FRONT EDGE OF THE BED.





## STEP 24

REMOVE THE FRONT TIE DOWN HOOK FROM THE INNER WALL OF THE TRUCK BED.

POSITION THE RIGHT SIDE FRONT MOUNTING BRACKET IN THE FRONT CORNER OF THE TRUCK BED AS SHOWN.

SECURE THE BRACKET WITH THE FASTENERS AS INDICATED, HAND TIGHTEN ONLY.

**REPEAT ON THE OPPOSITE SIDE OF THE VEHICLE WITH THE LEFT FRONT MOUNTING BRACKET.**





## STEP 25

REMOVE THE REAR TIE DOWN HOOK FROM THE INNER WALL OF THE TRUCK BED.

POSITION THE RIGHT SIDE REAR MOUNTING BRACKET IN THE BACK CORNER OF THE TRUCK BED AS SHOWN.

SECURE THE BRACKET WITH THE FASTENERS AS INDICATED, HAND TIGHTEN ONLY.


**REPEAT ON THE OPPOSITE SIDE OF THE VEHICLE WITH THE LEFT REAR MOUNTING BRACKET.**



## STEP 26

USE 4 PEOPLE TO LIFT THE ASSEMBLED SMARTCAP ONTO THE TRUCK BED.



TO AVOID DAMAGE TO THE D-RUBBER, DO NOT SLIDE THE SMARTCAP INTO PLACE.



## STEP 27

CHECK THAT THE SMARTCAP IS PROPERLY POSITIONED AND CENTERED ON THE TRUCK BED.

IT'S IMPORTANT THAT THE SMARTCAP IS NOT PUSHED TOO FAR FORWARD, LEAVING A GAP BETWEEN THE SMARTCAP AND THE CAB.



## STEP 28


WALK AROUND THE TRUCK BED TO MAKE SURE THE D-RUBBER FITMENT IS CORRECT AND THAT THE RUBBER LIP IS PROPERLY TUCKED UNDERNEATH THE CAP.

CORRECT D-RUBBER ORIENTATION



D-RUBBER

REAR FLANGE




TAILGATE

INCORRECT D-RUBBER ORIENTATION



D-RUBBER

REAR FLANGE





TAILGATE

## STEP 29

WITH A 5MM ALLEN KEY, LOOSELY TIGHTEN THE SMARTCAP RIGHT SIDE PANEL TO THE TOP OF THE TRUCK BED USING M8 BUTTON HEAD BOLT, M8 LOCK WASHER, AND M8 FENDER WASHER AS SHOWN BELOW.



**REPEAT ON THE OPPOSITE SIDE OF THE VEHICLE.**



## STEP 30

SECURE THE SMARTCAP TO THE RIGHT REAR MOUNTING BRACKET WITH THE FASTENERS AS INDICATED, HAND TIGHTEN ONLY.


**REPEAT ON THE OPPOSITE SIDE OF THE VEHICLE WITH THE LEFT REAR MOUNTING BRACKET.**



## STEP 31

SECURE THE SMARTCAP TO THE RIGHT REAR MOUNTING BRACKET WITH THE FASTENERS AS INDICATED, HAND TIGHTEN ONLY.



**REPEAT ON THE OPPOSITE SIDE OF THE VEHICLE WITH THE LEFT REAR MOUNTING BRACKET.**



## STEP 32

ONCE ALL THE FASTENERS ARE INSTALLED, PARTIALLY TIGHTEN WITH SOCKET WRENCH AS INDICATED.




**PARTIALLY TIGHTEN FASTENERS ON ALL FOUR CORNERS OF THE VEHICLE.**



## STEP 33

PRESS DOWN ON THE SMARTCAP TO ACHIEVE 2MM - 3MM COMPRESSION ON THE D-RUBBER AND CONTINUE TIGHTENING BRACKET FASTENERS WITH SOCKET WRENCH AS INDICATED.



**CONTINUE TIGHTENING FASTENERS ON ALL FOUR CORNERS OF THE VEHICLE.**



## STEP 34

ONCE SMARTCAP IS POSITIONED CORRECTLY, FULLY TIGHTEN UPPER FASTENERS USING A TORQUE WRENCH AND 13MM SOCKET TO 4.4 FT. LBS [6 NEWTON METERS]



**FULLY TIGHTEN UPPER FASTENERS ON ALL FOUR CORNERS OF THE VEHICLE.**



## STEP 35

ONCE SMARTCAP IS POSITIONED CORRECTLY, FULLY TIGHTEN LOWER FASTENERS USING A TORQUE WRENCH AND 13MM SOCKET TO 9 FT. LBS [12.2 NEWTON METERS]


**FULLY TIGHTEN LOWER FASTENERS ON ALL FOUR CORNERS OF THE VEHICLE.**



## STEP 36

USING A TORQUE WRENCH WITH A 5MM HEX KEY SOCKET, TIGHTEN THE M8 BUTTON HEAD BOLT TO 4.4 FT. LBS. [6 NEWTON METERS].

**REPEAT ON THE OPPOSITE SIDE OF THE VEHICLE.**




## THIRD BRAKE LIGHT



### IMPORTANT


- ▼ BE SURE THE VEHICLE IS TURNED OFF FOR THIS INSTALLATION.
- ▼ READ THROUGH THE ENTIRE PROCEDURE BEFORE STARTING AND FOLLOW THE STEPS CAREFULLY TO ENSURE THE THIRD BRAKE LIGHT AND TRAILER PLUG WILL FUNCTION PROPERLY.
- ▼ USE A TEST LIGHT TO CHECK FOR SUCCESSFUL INSTALLATION.

### LED TAIL LIGHT HARNESS



INCLUDED IN FITMENT KIT

### INCANDESCENT TAIL LIGHT HARNESS




IF YOUR RANGER IS EQUIPPED WITH INCANDESCENT TAILLIGHTS, PLEASE CONTACT [SUPPORT.NA@SMARTCAP.COM](mailto:SUPPORT.NA@SMARTCAP.COM) TO RECEIVE THE APPROPRIATE HARNESS.

## STEP 37

UNTIE THE THIRD BRAKE LIGHT EXTENSION HARNESS FROM WHERE IT IS ATTACHED TO THE SMARTCAP AT THE RIGHT REAR CORNER.

NOTE: THE CONNECTOR ON THE END OF THE HARNESS WILL NEED TO BE DE-PINNED IN ORDER TO ROUTE THROUGH THIS HOLE.






## STEP 38


DE-PIN CONNECTOR.




**TAKE NOTE OF WIRE ORIENTATION**




**A** USE A SCREWDRIVER TO PULL THE LOCK CLIP FORWARD.



**B** USE A PIN TOOL TO PRESS DOWN ON THE WIRE RELEASE TABS.



**C** WHILE PRESSING DOWN ON THE RELEASE TABS, REMOVE EACH OF THE WIRES FROM THE CONNECTOR.




## STEP 39

ROUTE THE THIRD BRAKE LIGHT EXTENSION HARNESS THROUGH THE HOLE AND DOWN TOWARDS THE INSIDE REAR BUMPER.



**BE SURE NOT TO DAMAGE TERMINALS**





## STEP 40

RE-ATTACH THE CONNECTOR TO THE THIRD BRAKE LIGHT HARNESS IN THE SAME FASHION AS IT WAS REMOVED.

SEE STEP 37

POSITIVE WIRE INDICATOR




## STEP 41

### WITH LED TAILLIGHTS

CONNECT THE LED T-HARNESS TO THE 2-PIN CONNECTOR AT THE END OF THE BRAKE LIGHT EXTENSION HARNESS.

LED T-HARNESS


THIRD BRAKE LIGHT HARNESS



## STEP 42

### WITH LED TAILLIGHTS

LOCATE THE 16-PIN CONNECTOR ON THE PASSENGER SIDE FRAME RAIL AND DISCONNECT IT.





## STEP 43

### WITH LED TAILLIGHTS

CONNECT THE T-HARNESS FEMALE CONNECTOR TO THE VEHICLE HARNESS MALE CONNECTOR.

CONNECT THE T-HARNESS MALE CONNECTOR TO THE VEHICLE HARNESS FEMALE CONNECTOR.


BUNDLE THE EXTRA T-HARNESS LENGTH UNDER THE VEHICLE AND SECURE WITH CABLE TIES



## STEP 44

### INCANDESCENT TAILLIGHTS


CONNECT THE INCANDESCENT T-HARNESS TO THE 2-PIN CONNECTOR AT THE END OF THE BRAKE LIGHT EXTENSION HARNESS.



## STEP 45

### INCANDESCENT TAILLIGHTS

LOCATE THE 6-PIN CONNECTOR ON THE PASSENGER SIDE FRAME RAIL AND DISCONNECT IT.




## STEP 46

### INCANDESCENT TAILLIGHTS

CONNECT THE T-HARNESS FEMALE CONNECTOR TO THE VEHICLE HARNESS MALE CONNECTOR.

CONNECT THE T-HARNESS MALE CONNECTOR TO THE VEHICLE HARNESS FEMALE CONNECTOR.



BUNDLE THE EXTRA T-HARNESS LENGTH UNDER THE VEHICLE AND SECURE WITH CABLE TIES



## STEP 47

### INCANDESCENT TAILLIGHTS

SECURE THE GROUND WIRE ON THE T-HARNESS TO THE CHASSIS AT A SUITABLE LOCATION UNDER THE VEHICLE.



## STEP 48

START THE TRUCK. NOTE THAT ON SOME MODELS, IT MAY TAKE UP TO 30 SECONDS FOR THE VEHICLE TO DETECT THE NEW CONNECTION. CHECK THE BRAKE LIGHTS AND TURN SIGNALS TO BE SURE THEY ARE FUNCTIONING PROPERLY.

ONCE YOU HAVE CONFIRMED THAT THE LIGHTS ARE WORKING CORRECTLY, SECURE THE HARNESS WITH CABLE TIES. **BE SURE NOT TO INTERFERE WITH ANY MOVING PARTS ON THE VEHICLE.**

# SMARTCAP<sup>®</sup>

THANKS FOR YOUR PURCHASE.  
PLEASE LET US KNOW IF YOU HAVE ANY QUESTIONS.

[SMARTCAP.COM](http://SMARTCAP.COM)

[SUPPORT.NA@SMARTCAP.COM](mailto:SUPPORT.NA@SMARTCAP.COM) - NORTH AMERICA  
[SUPPORT.SA@SMARTCAP.COM](mailto:SUPPORT.SA@SMARTCAP.COM) - REST OF WORLD



I-SHEET-NA-R2