


SMARTCAP®

INSTRUCTION GUIDE

TOYOTA TUNDRA EDITION

2019-2022





- ▼ **READ THROUGH THE ENTIRE INSTRUCTION GUIDE BEFORE STARTING THIS PROCEDURE AND FOLLOW THE STEPS CAREFULLY TO AVOID ANY DAMAGE TO THE COMPONENTS OR THE VEHICLE.**

SMARTCAP.COM - SUPPORT.NA@SMARTCAP.COM - NORTH AMERICA



P-IGUIDE-USA-R1


TOOLS REQUIRED




IMPORTANT

- ▼ USE ONLY THE TOOLS RECOMMENDED ABOVE.
- ▼ USE ONLY THE HARDWARE PROVIDED IN THIS KIT.
- ▼ ASSISTANCE WILL BE NEEDED FOR THIS INSTALLATION. FOUR PEOPLE ARE RECOMMENDED TO LIFT THE SMARTCAP ONTO THE VEHICLE.
- ▼ AVOID PINCHING OR CRUSHING HANDS AND FINGERS.
- ▼ INSPECT ALL KIT COMPONENTS FOR DAMAGE BEFORE ASSEMBLY.
- ▼ NEVER USE ACETONE OR THINNERS ON PAINTED PARTS.


COMPONENTS




LEFT PANEL




RIGHT PANEL



ROOF PANEL




REAR FLANGE






ASSEMBLY HARDWARE


(PRE-FASTENED TO FLANGES)




(PRE-FASTENED TO ROOF PANEL)



SPARE HARDWARE 1X




! STEP 1



IMPORTANT

- BE SURE TO REMOVE ALL FIVE PANELS FROM THEIR PACKAGING AND INSPECT THE PAINTED SURFACES PRIOR TO ASSEMBLY, AS SMARTCAP WILL NOT ACCEPT PAINT DAMAGE WARRANTY CLAIMS AFTER ASSEMBLY IS COMPLETED. IF MANUFACTURING IMPERFECTIONS OR SHIPPING DAMAGES ARE FOUND DO NOT CONTINUE WITH THE ASSEMBLY PROCESS AND CONTACT SUPPORT.NA@SMARTCAP.COM.





STEP 2

REMOVE ALL HARDWARE FROM ROOF PANEL



THIS SIDE UP
ROOF
PANEL



(USE THE CARDBOARD AS A WORK SURFACE)



10mm

M6
LOCK NUT



M6
FENDER
WASHER

10X SHORT BED

12X STANDARD BED


ROOF PANEL

STEP 3




RIGHT PANEL



STEP 4




STEP 5




STEP 6





STEP 7



STEP 8






STEP 9





STEP 10

REMOVE ALL HARDWARE FROM FRONT FLANGE




STEP 11





STEP 12

INSTALL HARDWARE
ALONG FRONT FLANGE
WITH BOLT ON INSIDE




HAND TIGHTEN IN THE
SEQUENCE SHOWN



14X





STEP 13





STEP 14

REMOVE ALL HARDWARE FROM REAR FLANGE




STEP 15



STEP 16

INSTALL HARDWARE
ALONG REAR FLANGE
WITH BOLT ON INSIDE



HAND TIGHTEN IN THE
SEQUENCE SHOWN



14X




BE SURE PANELS ARE FLUSH





STEP 17

TIGHTEN ALL HARDWARE
WITH TORQUE WRENCH
AND 10mm SOCKET




STEP 18

APPLY D - RUBBER
TO BOTTOM OF SMARTCAP




STEP 19





VEHICLE INSTALLATION

ASSEMBLY HARDWARE

THIN RUBBER PAD




THICK RUBBER PAD




5mm **1X**
FOAM SEAL TAPE

MOUNTING CLAMP



IMPORTANT

- ▼ ASSISTANTS WILL BE NEEDED FOR THIS INSTALLATION. FOUR PEOPLE ARE RECOMMENDED TO LIFT THE SMARTCAP ONTO THE VEHICLE.
- ▼ AVOID PINCHING OR CRUSHING HANDS AND FINGERS.
- ▼ BE SURE THE VEHICLE IS TURNED OFF FOR THIS INSTALLATION. READ THROUGH THE ENTIRE PROCEDURE BEFORE STARTING AND FOLLOW THE STEPS CAREFULLY TO ENSURE THE THIRD BRAKE LIGHT AND TRAILER PLUG WILL FUNCTION PROPERLY.
- ▼ USE A TEST LIGHT TO CHECK FOR SUCCESSFUL INSTALLATION.




STEP 20


REMOVE THE ADHESIVE BACKING FROM THE THICK RUBBER PAD.

STICK THE PADS UNDER THE SMARTCAP'S EDGE AT RECOMMENDED LOCATION OF MOUNTING CLAMPS


PEEL AWAY ADHESIVE BACKING



THICK RUBBER PAD




NOTE THE RECOMMENDED LOCATIONS FOR THE MOUNTING CLAMPS INSIDE BOTH SIDES OF THE SMARTCAP.





NOTE: TWO EXTRA PADS CAN BE INSTALLED AS SPACERS FOR FURTHER SUPPORT

THICK RUBBER PAD





STEP 21

INSPECT THE TRUCK BED. IF FRONT EDGE IS LOWER THAN THE SIDES, ADD FOAM SEAL TAPE TO THE FRONT EDGE OF THE BED





STEP 22



LIFT THE ASSEMBLED SMARTCAP ONTO THE TRUCK BED

CHECK THAT THE SMARTCAP IS PROPERLY POSITIONED AND CENTERED ON THE TRUCK BED


! BE SURE TO NOT SCRAPER OR DAMAGE THE D-RUBBER



STEP 23


REMOVE THE ADHESIVE BACKING FROM THE THIN RUBBER PAD

WITH THE EXCEPTION OF THE REAR CORNERS, PLACE THE THIN RUBBER PADS NEXT TO GUSSETS ON BOTH SIDES OF THE CAP




STEP 24

INSTALL LOWER CLAMP ARMS INTO RAIL INSIDE TRUCK BED AND REASSEMBLE UPPER AND LOWER CLAMP ARMS



STEP 25

INSTALL MOUNTING CLAMPS ON TOP OF THIN RUBBER PADS USING A TORQUE WRENCH AND 13MM SOCKET TO TIGHTEN TO 4.4 FT. LBS (6 NEWTON METERS)





THIRD BRAKE LIGHT CONNECTOR INSTALLATION



IMPORTANT


- ▼ BE SURE THE VEHICLE IS TURNED OFF FOR THIS INSTALLATION.
- ▼ READ THROUGH THE ENTIRE PROCEDURE BEFORE STARTING AND FOLLOW THE STEPS CAREFULLY TO ENSURE THE THIRD BRAKE LIGHT AND TRAILER PLUG WILL FUNCTION PROPERLY.
- ▼ USE A TEST LIGHT TO CHECK FOR SUCCESSFUL INSTALLATION.



STEP 26

LOCATE THE 7-WAY TRAILER CONNECTOR
AT THE HITCH OR INSIDE THE BUMPER

DISCONNECT THE PLUG FROM THE BACK
OF THE 7-WAY CONNECTOR




STEP 27

PLUG THE NEW T-HARNESS INTO THE
BACK OF THE 7-WAY CONNECTOR

CONNECT THE ORIGINAL PLUG INTO
THE FEMALE SIDE OF THE T-HARNESS

BE SURE PLUGS ARE FULLY INSERTED
AND LOCKING TABS ARE IN PLACE.




STEP 28

UNTIE THE THIRD BRAKE LIGHT HARNESS FROM WHERE IT IS ATTACHED TO THE SMARTCAP

REMOVE THE GROMMET COVER AT THE TRUCK BED WALL


ROUTE THE THIRD BRAKE LIGHT HARNESS IN THROUGH THE GROMMET PANEL OPENING AND OUT THROUGH THE TAILLIGHT CAVITY



STEP 29

ROUTE THE T-HARNESS ALONG THE INSIDE OF THE REAR BUMPER WITH THE 2-PIN PLUG GOING UP TOWARDS THE DRIVER SIDE TAILLIGHT

CONNECT THE 2-PIN FEMALE PLUG OF THE T-HARNESS INTO THE MALE 2-PIN PLUG OF THE THIRD BRAKE LIGHT HARNESS



STEP 30

START THE TRUCK. NOTE THAT ON SOME MODELS, IT MAY TAKE UP TO 30 SECONDS FOR THE VEHICLE TO DETECT THE NEW CONNECTION. CHECK THE BRAKE LIGHTS AND TURN SIGNALS TO BE SURE THEY ARE FUNCTIONING PROPERLY.

ONCE YOU HAVE CONFIRMED THAT THE LIGHTS ARE WORKING CORRECTLY, SECURE THE HARNESS WITH CABLE TIES. **BE SURE NOT TO INTERFERE WITH ANY MOVING PARTS ON THE VEHICLE.**



THANKS FOR YOUR PURCHASE.
PLEASE LET US KNOW IF YOU HAVE ANY QUESTIONS.

SMARTCAP.COM - SUPPORT.NA@SMARTCAP.COM - NORTH AMERICA

